MV AUTO PARTS

FULL CATALOGUE

Wholesale catalogue - Sprinter / Crafter / Transit

Crystal Luggage Rack

Net/Gross: 25 / 28 kg | Pcs/box: 1 | Box: 380×45×35 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Wheel Caps

OEM: 9064000225

Models: Sprinter 904, Sprinter 906, Sprinter 901 | Years: 1995-2020 | Net/Gross: 0.35 / 8.2 kg | Pcs/box: 20 | Box: 50×50×40 | HS code: 870870 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Prestige Luggage Rack

Net/Gross: 25 / 28 kg | Pcs/box: 1 | Box: 380×45×35 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Door Handle Covers

Models: Sprinter 906, Sprinter 901 | Years: 1995-2020 | Finish: Хром или цвет кузова (белый / бежевый) | Net/Gross: 0.3 / 17 kg | Pcs/box: 50 | Box: 60×40×30 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Front Bumper Covers

Models: Sprinter 901, Sprinter 904, Sprinter 906 | Net/Gross: 3 / 7.1 kg | Pcs/box: 2 | Box: 190×40×30 | HS code: 870810 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Venus Rack

Net/Gross: 22 / 24.7 kg | Pcs/box: 1 | Box: 380×45×35 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Wind Deflectors

Models: Sprinter 901, Sprinter 904, Sprinter 906 | Net/Gross: 0.6 / 13.7 kg | Pcs/box: 20 | Box: 100×30×25 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Chassis — Ares

Net/Gross: 35 / 39 kg | Pcs/box: 1 | Box: 400×40×20 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Front Visors

Net/Gross: 3 / 3.8 kg | Pcs/box: 1 | Box: 200×40×15 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Chassis — Prestige

Net/Gross: 35 / 39 kg | Pcs/box: 1 | Box: 400×40×20 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Under/Above Window Profiles

Net/Gross: 4 / 22.5 kg | Pcs/box: 5 | Box: 360×20×15 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Hood Deflectors

Net/Gross: 1.2 / 13.7 kg | Pcs/box: 10 | Box: 100×40×30 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Aluminium Seat Rails

Material: Алюминий | Net/Gross: 5 / 55.5 kg | Pcs/box: 10 | Box: 410×20×15 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Chrome Trim

Net/Gross: 1 / 22.5 kg | Pcs/box: 20 | Box: 150×30×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Ceiling Moldings

Net/Gross: 3 / 17 kg | Pcs/box: 5 | Box: 360×20×15 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Aluminium Step Corner

Material: Алюминий | Net/Gross: 0.8 / 18.1 kg | Pcs/box: 20 | Box: 60×30×25 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Seats

Net/Gross: 12 / 13.7 kg | Pcs/box: 1 | Box: 100×60×55 | HS code: 940120 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Thresholds

Net/Gross: 1 / 22.5 kg | Pcs/box: 20 | Box: 100×30×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Handle Cover for Auto Door

Net/Gross: 0.2 / 11.5 kg | Pcs/box: 50 | Box: 40×30×25 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Seat Covers

Net/Gross: 0.5 / 17 kg | Pcs/box: 30 | Box: 60×40×40 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Aero Bonnet Deflector (Premium 4mm Acrylic)

Models: Ford Transit, VW Crafter, Sprinter 906, Sprinter W907 | Years: 2006-2018 | Material: Акрил PMMA 4 мм, UV-стойкий | Finish: Тёмный дым, глянец | Net/Gross: 1.5 / 17 kg | Pcs/box: 10 | Box: 100×40×30 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Structural External Sunvisor

Models: Ford Transit, VW Crafter | Material: Литой акрил 5 мм или ABS; кронштейны — сталь с порошковой покраской | Finish: Тёмный дым или матовый чёрный | Net/Gross: 6 / 7.1 kg | Pcs/box: 1 | Box: 200×45×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Textured Wheel Arch Fender Flares (Set)

Models: Ford Transit, VW Crafter | Material: Термоформованный ABS | Finish: Матовый чёрный, текстура (под покраску) | Net/Gross: 6 / 7.1 kg | Pcs/box: 1 | Box: 120×60×40 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Anti-Slip Rear Bumper Sill Step Guard

Models: Ford Transit, VW Crafter | Material: ABS 3,5 мм или нержавеющая сталь 304 | Finish: Рифлёная противоскользящая поверхность | Net/Gross: 1.5 / 17 kg | Pcs/box: 10 | Box: 160×25×15 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Metal & Glass Roof Hatches

Net/Gross: 6 / 7.1 kg | Pcs/box: 1 | Box: 70×70×25 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

MV AUTO PARTS

FULL CATALOGUE

Wholesale catalogue - Sprinter / Crafter / Transit

Air Channels (LED)

Net/Gross: 12 / 13.7 kg | Pcs/box: 1 | Box: 370×40×30 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Bus Body Parts

HS code: 870829 | MOQ: 50 pcs | Availability: Made to order

Corner Profiles

Net/Gross: 2 / 22.5 kg | Pcs/box: 10 | Box: 300×25×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

USB Ports

Net/Gross: 0.1 / 11.5 kg | Pcs/box: 100 | Box: 40×30×20 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

Motors for Automatic Doors

Net/Gross: 7 / 8.2 kg | Pcs/box: 1 | Box: 60×30×25 | MOQ: 50 pcs | Lead time: 20 days | Availability: Made to order

REAR BUMPER REINFORCEMENT BRACKET - SPRINTER / CRAFTER — MRS 201

OEM: A9063108237

Models: VW Crafter, Sprinter 906 | Material: Stamped steel | Net/Gross: 2.5 / 14.3 kg | Pcs/box: 5 | Box: 160×25×16 | HS code: 870810 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

MERCEDES SPRINTER HOOD 2000-2006 W901-904 — MRS 302

OEM: 9017500202

Models: Sprinter 904, Sprinter 901 | Years: 2000-2006 | Material: Stamped steel | Net/Gross: 9 / 10.4 kg | Pcs/box: 1 | Box: 145×80×8 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

MERCEDES SPRINTER HOOD WITH WASHER JET HOLE 2000-2006 W901-904 — MRS 303

OEM: 9017500202

Models: Sprinter 904, Sprinter 901 | Years: 2000-2006 | Material: Stamped steel | Net/Gross: 9 / 10.4 kg | Pcs/box: 1 | Box: 145×80×8 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER / CRAFTER REAR FENDER SUPPORT PANEL - RIGHT — MRS 206 R

OEM: 9066370135

Models: VW Crafter, Sprinter 906 | Side: Right | Material: Stamped steel | Net/Gross: 1 / 11.5 kg | Pcs/box: 10 | Box: 50×35×30 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER / CRAFTER REAR FENDER SUPPORT PANEL - LEFT — MRS 206 L

OEM: 9066370035

Models: VW Crafter, Sprinter 906 | Side: Left | Material: Stamped steel | Net/Gross: 1 / 11.5 kg | Pcs/box: 10 | Box: 50×35×30 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER / CRAFTER SIDE SILL PANEL - REAR OF WHEEL - RIGHT — MRS 111 R

OEM: A9066376309

Models: VW Crafter, Sprinter 906 | Side: Right | Material: Stamped steel | Net/Gross: 2 / 22.5 kg | Pcs/box: 10 | Box: 125×25×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER / CRAFTER SIDE SILL PANEL - REAR OF WHEEL - LEFT — MRS 111 L

OEM: A9066376209

Models: VW Crafter, Sprinter 906 | Side: Left | Material: Stamped steel | Net/Gross: 2 / 22.5 kg | Pcs/box: 10 | Box: 125×25×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER / CRAFTER SIDE SILL PANEL - REAR OF WHEEL LONG - RIGHT — MRS 113 R

OEM: 9066376509
Models: VW Crafter, Sprinter 906 | Side: Right | Material: Stamped steel | Net/Gross: 2 / 22.5 kg | Pcs/box: 10 | Box: 130×25×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER / CRAFTER SIDE SILL PANEL - REAR OF WHEEL LONG - LEFT — MRS 113 L

OEM: 9066376409
Models: VW Crafter, Sprinter 906 | Side: Left | Material: Stamped steel | Net/Gross: 2 / 22.5 kg | Pcs/box: 10 | Box: 130×25×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER / CRAFTER SIDE SILL PANEL - FRONT OF REAR WHEEL - RIGHT — MRS 110 R

OEM: A9066375709
Models: VW Crafter, Sprinter 906 | Side: Right | Material: Stamped steel | Net/Gross: 2.2 / 24.7 kg | Pcs/box: 10 | Box: 130×25×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER / CRAFTER SIDE SILL PANEL - FRONT OF REAR WHEEL - LEFT — MRS 110 L

OEM: A9066375609
Models: VW Crafter, Sprinter 906 | Side: Left | Material: Stamped steel | Net/Gross: 2.2 / 24.7 kg | Pcs/box: 10 | Box: 130×25×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER REAR CARGO DOOR PANEL - RIGHT (2006-2018) — MRS 114 R

OEM: A9067400705
Models: Sprinter 906 | Years: 2006-2018 | Side: Right | Material: Stamped steel | Net/Gross: 6 / 7.1 kg | Pcs/box: 1 | Box: 160×80×8 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER REAR CARGO DOOR PANEL - LEFT (2006-2018) — MRS 114 L

OEM: A9067400005
Models: Sprinter 906 | Years: 2006-2018 | Side: Left | Material: Stamped steel | Net/Gross: 6 / 7.1 kg | Pcs/box: 1 | Box: 160×80×8 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER REAR BODY PANEL 2000-2006 W901-W904 — MRS 301

OEM: A9016120114
Models: Sprinter 904, Sprinter 901 | Years: 2000-2006 | Material: Stamped steel | Net/Gross: 0.55 / 6.6 kg | Pcs/box: 10 | Box: 70×30×25 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER FRONT LOWER APRON PANEL (STEP PANEL) - RIGHT — MRS 104 R

OEM: 9066302600
Models: Sprinter 906 | Side: Right | Material: Stamped steel | Net/Gross: 3 / 13.7 kg | Pcs/box: 4 | Box: 100×40×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER FRONT LOWER APRON PANEL (STEP PANEL) - LEFT — MRS 104 L

OEM: 9066302400
Models: Sprinter 906 | Side: Left | Material: Stamped steel | Net/Gross: 3 / 13.7 kg | Pcs/box: 4 | Box: 100×40×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER FRONT GRILLE SURROUND FRAME — MRS 205

OEM: A9068880051
Models: Sprinter 901, Sprinter 904, Sprinter 906 | Material: Stamped steel | Net/Gross: 1 / 6 kg | Pcs/box: 5 | Box: 110×25×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER MIDDLE DOOR OPPOSITE SILL PANEL — MRS 112

OEM: A9066375009
Models: Sprinter 901, Sprinter 904, Sprinter 906 | Material: Stamped steel | Net/Gross: 2.4 / 26.9 kg | Pcs/box: 10 | Box: 140×25×20 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER W906 HOOD (BONNET) — MRS 202

OEM: A9068800257
Models: Sprinter 906 | Material: Stamped steel | Net/Gross: 9 / 10.4 kg | Pcs/box: 1 | Box: 150×90×8 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER W906 FRONT BUMPER REINFORCEMENT BAR — MRS 200

OEM: A9066202500
Models: VW Crafter, Sprinter 906 | Material: Stamped steel | Net/Gross: 2 / 11.5 kg | Pcs/box: 5 | Box: 170×20×25 | HS code: 870810 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER W906 FRONT FENDER - RIGHT (2013-2019) — MRS 203 R

OEM: 9068810201
Models: Sprinter 906 | Years: 2013-2019 | Side: Right | Material: Stamped steel | Net/Gross: 3 / 17 kg | Pcs/box: 5 | Box: 95×55×35 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER W906 FRONT FENDER - LEFT (2013-2019) — MRS 203 L

OEM: 9068810101
Models: Sprinter 906 | Years: 2013-2019 | Side: Left | Material: Stamped steel | Net/Gross: 3 / 17 kg | Pcs/box: 5 | Box: 95×55×35 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER W907 SIDE SILL PANEL - REAR OF WHEEL - RIGHT (2018+) — MRS 117 R

OEM: A9076370900
Models: Sprinter W907 | Years: 2018+ | Side: Right | Material: Stamped steel | Net/Gross: 1.2 / 13.7 kg | Pcs/box: 10 | Box: 100×35×25 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER W907 SIDE SILL PANEL - REAR OF WHEEL - LEFT (2018+) — MRS 117 L

OEM: A9076370800
Models: Sprinter W907 | Years: 2018+ | Side: Left | Material: Stamped steel | Net/Gross: 1.2 / 13.7 kg | Pcs/box: 10 | Box: 100×35×25 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER W907 SIDE SILL PANEL - FRONT OF REAR WHEEL - RIGHT (2018+) — MRS 116 R

OEM: A9076371800
Models: Sprinter W907 | Years: 2018+ | Side: Right | Material: Stamped steel | Net/Gross: 1.3 / 14.8 kg | Pcs/box: 10 | Box: 100×35×25 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER W907 SIDE SILL PANEL - FRONT OF REAR WHEEL - LEFT (2018+) — MRS 116 L

OEM: A9076371700
Models: Sprinter W907 | Years: 2018+ | Side: Left | Material: Stamped steel | Net/Gross: 1.3 / 14.8 kg | Pcs/box: 10 | Box: 100×35×25 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER / CRAFTER FRONT FENDER LOWER PANEL - RIGHT — MRS 204 R

OEM: A9066302107
Models: VW Crafter | Side: Right | Material: Stamped steel | Net/Gross: 0.8 / 9.3 kg | Pcs/box: 10 | Box: 60×35×30 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order

SPRINTER / CRAFTER FRONT FENDER LOWER PANEL - LEFT

MRS 204 L

OEM: A9066302007

Models: VW Crafter | Side: Left | Material: Stamped steel | Net/Gross: 0.8 / 9.3 kg | Pcs/box: 10 | Box: 60×35×30 | HS code: 870829 | MOQ: 50 pcs | Lead time: 25 days | Availability: Made to order